

TRUE REPLACEMENT HANDLE INSTALLATION INSTRUCTIONS



1. Apply silicone sealant or epoxy to the back of the handle and in the slot as shown.
2. Slide the handle into position over the old handle (Note: It is generally not necessary to remove any of the old handle) Gently tap the handle into position if needed
3. Snap/press handle into place.
4. Tape handle to door around outer edge until glue sets.